

Container geometry



Container diameter: 32m

Filling level: 9,5m

► Substrate: TS 15%

Agitator: 9x Varibull paddle agitator (10 rpm)


Circulation capacity - without turbulence and entrainment: 15624 m³/h


Circulation capacity - with turbulence and entrainment: 52800 m³/h


Velocity of the medium after the simulation has reached a steady state: 0.222m /s

CFD-Geometry










CFD Medium Definition




- A non-Newtonian behavior of the fluid was assumed in the simulation.
- Definition of "non-Newtonian fluid":


A non-Newtonian fluid differs from "normal" fluids in that it has a variable viscosity. A non-Newtonian fluid changes its viscosity depending on the shear rate that occurs. For example, for the fluid (see diagram below), the viscosity at a shear rate of 85/s is about 1.0 Pas. Consequently, the same fluid may have different viscosities at different locations in a tank, depending on the shear rates present at a particular location. This non-Newtonian behavior was included in the simulation. The shape of the curve is based on experience and measurements.




Streamlines










Floating layer (9,5m)

0.500 0.464 0.429 0.393 0.367 0.321 0.250 0.214 0.179 0.143 0.107 0.071






Level 7.55m center agitator shaft

0.500 0.464 0.429 0.393 0.357 0.256 0.250 0.214 0.179 0.143 0.107 0.071






Level 3.3m center agitator shaft

- 0.500 - 0.464 - 0.429 - 0.393 - 0.357 - 0.321 - 0.286 - 0.250 - 0.214 - 0.179 - 0.143

0.107 0.071 0.036






Container bottom (0m)


- 0.500 - 0.464 - 0.429 - 0.393 - 0.357 - 0.250 - 0.214 - 0.179 - 0.143 - 0.107 - 0.071 - 0.036 0






Cross section of the average speed







Conclusion



- ► The velocity of the medium after the simulation reached a stable value of 0.222m/s
- Experience shows that the value is 0.18 m/s, thus complete mixing is achieved

The values are to be understood as samples. No project-specific design.



Thank you for your attention!

Biogastechnik Süd GmbH Am Schäferhof 2 88316 Isny, Germany

Phone: +49 7562 97085 - 40 Fax: +49 7562 97085 - 50

vertrieb@biogastechnik-sued.de www.biogastechnik-sued.de